

## Care and Use Instructions

## **A**CAUTION

- Careful. The beverage you are about to enjoy may be very hot. For best results always use caution.
- · Keep out of reach of children when filled with hot liquids.
- Prior to drinking, make sure the lid is properly threaded to the body and screwed down completely.
- If filling with boiling liquid, allow liquid to cool down WITH THE LID OFF for at least 3 minutes before attaching the lid.
- DO NOT overfill. Fill liquids to just below the threading in the body.
- · DO NOT microwave or freeze.
- DO NOT use cleaners containing bleach, chlorine, abrasives, and/or other harsh chemicals.
- DO NOT continue to use product if damaged.
- DO NOT carry bottles containing liquid in bags to help prevent accidental opening.

## CLEANING INSTRUCTIONS

- Wash thoroughly before first use.
- RINSE LID IMMEDIATELY AFTER EACH USE with warm water.
- Lid and any UNPAINTED stainless steel body are top-rack dishwasher safe.
  HAND-WASH ONLY any PAINTED stainless steel body.
- To wash by hand, soak the lid for 10 minutes in hot, soapy tap water.
  Hand-wash the body with warm water and a mild detergent. Rinse both the lid and body thoroughly before use.
- ALWAYS STORE MUG WITH LID REMOVED to allow parts to dry completely.